

Type NEXT STEP, 19" Panel construction:



1. Corner Profiles are fastened in one end at bottom part fitting the casted corners.



2. The top part is mounted on the four corner profiles.



3. Pivot screws inside the casted cornerparts are tightend firmly.



4. Cableguide is placed in the back of the panel.



5. Fasten 19" rails in each end by placing klipnut in slide of bearing. Screw in screws into top- and bottom.



6. Sides and backpanel are all lifted on the hinges, closed and locked at the droplock brackets on the cornerprofiles.



7. The door is mounted on hinges and closed.



8. Side- and back panel are secured by a red lock at the bottom.



9. In the topplate a sliding plate is adjusted for cable entrance. The blindplates can be exchanged by fans.